



Repair Station #S7HR883J EASA# .145.5336 Air Agency Certificate Number S7HR883J JAA Approval Number 5336

Boeing 737 Overhaul Capabilities

A15802	CLOCK	0856AE16	PROBE
A6850C5	COCKPIT LIGHT	0856AE18	PROBE
BA08032-230	BALLAST	0856AE19	PROBE
BR9172-501	LIGHT ASSY	10-0015-X	LIGHT ASSY
B711-X	INDICATOR	10-1006-X	LIGHT ASSY
B712-X	INDICATOR	10-1042-X	LENS
CE530324	HANDSET	10-1070-1	HOUSING
CE602-1483	MICROPHONE	10-1073-SER	LENS
CGAB1400-00	SMOKE DETECTOR	10-1074-SER	SIGN
E709-01-001	CEILING LIGHT	10-1075-SER	SIGN
E709-03-001	CEILING LIGHT	10-1076-SER	HOUSING
E709-04-001	CEILING LIGHT	10-1077-SER	SIGN
JG1052 SER	ALERT IND.	10-1113-3	DOME LIGHT
JG298A5	INDICATOR	10-1114-3	LIGHT ASSY
JG865C1	INDICATOR	10-1270-1	SIGN
JG865C3	INDICATOR	10-1327-SER	LIGHT ASSY
JG908A41	INDICATOR	10-1331-SER	LENS
JG908A57	INDICATOR	10-1443-SER	LENS
PU90-400 SER	SMOKE DETECTOR	10-1581-SER	LIGHT ASSY
RDAX1012	MULTIPLEXER	1014A	POWER SUPPLY
RDAX1017	DECODER	102AH2AG	PROBE
RDAX1302	AUG. MUX	102JE2FG	PROBE
RDAX3002A	DECODER	1024-1	DIMMER
RDAX4312	DECODER	1024-2	DIMMER
RDAX4331	DECODER	107C800-X	MICROPHONE
RDAX6632D1	PCU	107C900-X	MICROPHONE
RDAX6633M1	PCU	11-0283-3	LIGHT
RDAX6711-01	AUDIO UNIT	11-6537-X	LIGHT SWITCH
RDAX6712-01	AUDIO UNIT	1247-1	BALLAST
SEL0C19 SER	INDICATOR	129666-X	SENSOR
SEL04AD	INDICATOR	129694-X	SENSOR
SEL04T	INDICATOR	15-0026-5	LIGHT ASSY
SELO4W	INDICATOR	15-0069-X	LIGHT ASSY
0123FA2	SENSOR	15-0712-X	LIGHT ASSY
033638	BLOWER	15-0726-X	LIGHT ASSY
033638500	BLOWER	15-0797-X	LIGHT ASSY
05939-XXX	BALLAST	161714-01-01	MODE SEL. PANEL
0851HT	PROBE	161714-02-01	MODE SEL. PANEL
162BL502	INDICATOR	30-0418-X	LIGHT ASSY
162BL701	INDICATOR	30-0434-11	LIGHT ASSY
162BL704 SER	INDICATOR	30-0808-XX	LIGHT ASSY
162BL801	INDICATOR	30-0837-XX	LIGHT ASSY
162BL802/802A	INDICATOR	30-0906-XX	LIGHT ASSY
162BL803/803A	INDICATOR	30-0909-XX	LIGHT ASSY



Repair Station #S7HR883J EASA# .145.5336 Air Agency Certificate Number S7HR883J JAA Approval Number 5336

162BL804A	INDICATOR	30-1401-3	LIGHT ASSY
162BL902	INDICATOR	30-2392-4	LIGHT ASSY
162BL903	INDICATOR	30-2481-3	LIGHT ASSY
162BL906	INDICATOR	30-2505-3	LIGHT ASSY
162BL907	INDICATOR	30-2506-3	LIGHT ASSY
163BL511	INDICATOR	30-284-2	SMOKE DETECTOR
163CV59	INDICATOR	30-326-8	AMP.
163CV64	INDICATOR	3000-46-XX	TEMP. SW.
163CP80	INDICATOR	305454-14-1	SPEED SWITCH
1646-1-6	BALLAST	305593-X	SPEED SWITCH
1646-1-7	CONTROLLER	3176311002-XXX	LIGHT SWITCH
1703-775-12	HEAT SENSOR	3186301001-XXX	LIGHT ASSY
1707C	HEAT SENSOR	3186301002-XXX	LIGHT SWITCH
171795-0X	AUDIO SEAT BOX	34265-8	LIGHT ASSY
1857-1	ALT.ALERT	35805-0	FIRE CONTROL
2CM9ABY7	TACH. GEN	3609480-X	SPEED SWITCH
20-035008-XXX	CARD/MODULE	3876259-X	SPEED SWITCH
20046-1	HEADPHONE	393020-XXX	FUEL QUAN. IND.
2156-45	SMOKE DET.	393026-XXX	FUEL QUAN. IND.
2156-55	SMOKE DET.	393080-XXX	FUEL QUAN. IND.
231-1/-2	WINDOW HEAT	393086-XXX	FUEL QUAN. IND.
255-5/-52	PA. AMPLIFIER	40-0112-X	LIGHT ASSY
2600-03-01	CLOCK	40-0135-X	LIGHT ASSY
2600-04-01	CLOCK	40-0149-X	LIGHT ASSY
2610-07-1	CLOCK	40-0173-X	ROT.BEACON ASSY
285A1710-X	ATT. PANEL	40-0196-X	LIGHT ASSY
285A1720-X	ATT. MODULE	4041-XX	LIGHT INTERIOR
285A1730-X	ATT.PANEL	4042-XX	LIGHT INTERIOR
285N0028-X	FIRE SYS. TEST MOD.	417A6110-XX	ATT. PANEL
285U0037-X	RADIO/COM PANEL	417N2117-X	DRAIN MAST
285W0024-X	HANDSET	417N3011-XXX	PSU
30-0213-XX	LIGHT ASSY	417N3051-XXX	PSU
30-0234-XX	LIGHT ASSY	417N3100-XXX	PSU
30-0407-X	LIGHT ASSY	417N3200-XXX	PSU
30-0408-X	LIGHT ASSY	4336731001-XXXX	LIGHT
30-0409-X	LIGHT ASSY	4346731004-XXXX	LIGHT SWITCH
4346741005-XXXX	LIGHT ASSY	60-1254-1	BATTERY PACK
4346741007-1019	SWITCH	60-1321-1	BATTERY PACK
4346741009-XXXX	LIGHT ASSY	60-2388-1	POWER SUPPLY
4346741031-XXXX	LIGHT ASSY	600-0108-1	OVEN CONTROL
4346741033-XXXX	LIGHT ASSY	605675-X	FAN ASSY
4346748705-XXXX	LIGHT ASSY	606802-X	FAN ASSY
45-0057-1	LIGHT ASSY	606805-2	FAN ASSY
45-0083-X	LIGHT ASSY	607400-1	TEMP. SELECTOR
45-0100-1	LIGHT ASSY	607152-1-1	TEMP. SELECTOR
45-0351-X	LIGHT ASSY	607152-2-1	TEMP. SELECTOR
46339-X	AC MOTOR	607400-X	TEMP. SELECTOR



Repair Station #S7HR883J EASA# .145.5336 Air Agency Certificate Number S7HR883J JAA Approval Number 5336

472094	FIRE DETECTOR	606510-2/3	TEMP. CONTROL
472299	FIRE DETECTOR	607512-1-1	TEMP. SENSOR
472581	FIRE DETECTOR	607518-2	TEMP. CONTROL
472582	FIRE DETECTOR	61-36-2	BALLAST
472583	FIRE DETECTOR	61-46-1	BALLAST
472584	FIRE DETECTOR	61-47-1	BALLAST
472619	FIRE DETECTOR	61-48-2	BALLAST
472621	FIRE DETECTOR	610BL3	BALLAST
472622	FIRE DET. MODULE		
473597-5	FIRE DETECTOR	622814-X	TEMP. CONTROL
50-0128-X	LIGHT ASSY	622878-X	TEMP. SENSOR
50-0199-X	LIGHT ASSY	624018-X	TEMP. SENSOR
5045-1	AUDIO SEL. PANEL	624116-1	TEMP. CONTROL
5045-1-2	AUDIO SEL. PANEL	624118-1	TEMP. SENSOR
516023-1	AC MOTOR	627570-1	TEMP. SENSOR
516024-X	AC MOTOR	63274-000	HEADSET
516029-2-1	AC MOTOR	63274-008	HEADSET
516035-1-1	AC MOTOR	63600-001	HEADSET
516504-1	AC MOTOR	63999-00X	MICROPHONE
522782	VIB. MON. IND	641100-3	THERMO SWITCH
5394-X	FIRE CONTROL	641121-1	THERMO SWITCH
5401	FIRE DETECTOR	641137-1	THERMO SWITCH
5402	FIRE DETECTOR	64300-000	HEADSET
5403	FIRE DETECTOR	64400-000	HEADSET
548376-X	TEMP. CONTROL	645055-X	FAN ASSY
548380-X	TEMP. SELECTOR	645242-1	FAN ASSY
548382-2	TEMP. SELECTOR	645405-1	FAN ASSY
548384-1	TEMP. SENSOR	645670-1	FAN ASSY
548388-1	TEMP. SENSOR	65-0028-XX	LIGHT ASSY
548392-1	TEMP. ELEMENT	65-0294-XX	LIGHT ASSY
5499-01	FIRE DETECTOR	65-45260-XXX	PSU
5499-02	FIRE DETECTOR	65-45314-XX	MODULE
572756-1	THERMO SWITCH	65-52804-XXX	WINDOW HEAT
572757-1	THERMO SWITCH	65-52807-X	OHEAT SENSOR
60-0540-1	BATTERY PACK	65-52812-XXX	DIMMING PANEL
65-54499-XX	AUREL WARNING	8DJ81LXH2	TACH. IND.
65-57448-XX	FIRE DET PANEL	8DJ81LYT2	TACH. IND.
65-57906-X	ATT. AMPLIFIER	8DJ81LYT4	TACH. IND.
65-58163-XXX	FLT. INST. CONT.	8DJ81LYV2	TACH. IND.
65-58220-X	GALLEY LIGHT	8DJ81LYV4	TACH. IND.
65-59359-XX	INST. LIGHT MOD.	8DJ81WAG2	TACH. IND.
65-64960-X	ANN. LIGHT MODULE	8DJ81WAG4	TACH. IND.
65-79164-XX	PSU	8DJ81WAG4U	TACH. IND.
65-79165-XX	PSU	8DJ81WBG4	TACH. IND.
65-79166-XX	PSU	8DJ81WBG4U	TACH. IND.
65-82721-XX	PSU	8DJ81WBL4	TACH. IND.
65-86274-XX	PSU	8DJ81WBM4	TACH. IND.



Repair Station #S7HR883J EASA# .145.5336 Air Agency Certificate Number S7HR883J JAA Approval Number 5336

65-86412-XX	PSU	8DJ88GAC1	F/F IND.
65-86413-XX	PSU	8DJ88LWX3	F/F IND.
65C10321-XX	PSU	8TJ80GAA1	F/F SUPPLY
65C10324-XX	PSU MODULE	8TJ88GAC1	F/F SUPPLY
65C10590-X	PSU	8TJ95GAA1	F/F SUPPLY
65C10916-13	MODULE	8TJ95GAB2	F/F SUPPLY
65C12930-XX	AUDIO/COM SEL.	8TJ95GAB3	F/F SUPPLY
65C16839-XXX	PSU	801240-X	FAN ASSY
65C21465-XX	WINDOW HEAT MOD	81000-33802	LIGHT ASSY
65C21854-2	AUREL WARNING	81000-33807	LIGHT ASSY
65V10153-X	PSU	81000-33902	LIGHT ASSY
65V10605-XX	PSU	81000-33903	LIGHT ASSY
65V10695-101	PSU	81000-33904	LIGHT ASSY
65V10794-XXX	PSU	81000-37601	LIGHT ASSY
6577-1	FAN ASSY	81000-37602	LIGHT ASSY
6577-2	FAN ASSY	81000-37701	LIGHT ASSY
6594	FAN ASSY	81000-37703	LIGHT ASSY
6594-01	FAN ASSY	81000-37704	LIGHT ASSY
6672-01	FIRE DETECTOR	81000-37705	LIGHT ASSY
6676	FIRE DETECTOR	81000-37801	LIGHT ASSY
6678	FIEW DETECTOR	81000-37802	LIGHT ASSY
69-34D	BALLAST	81000-37901	LIGHT ASSY
698427-XX	APU COOLING FAN	81000-38201	LIGHT ASSY
70-0240-X	ALARM PANEL	81000-38202	LIGHT ASSY
75-0123-11	LIGHT ASSY	81000-38203	LIGHT ASSY
75-0149-XX	LIGHT ASSY	81000-38204	LIGHT ASSY
75-0161-1	LIGHT ASSY	81000-38301	LIGHT ASSY
75-0169-X	LIGHT PANEL	8171-1	BALLAST
8DJ125LYA5	FUEL FLOW IND.	8184-1	BALLAST
8DJ125LYB5	FUEL FLOW IND.	82000-49001	SIGN
8DJ179KBA2	TEMP. IND.	82000-49002	SIGN
8DJ179KDA1	TEMP. IND.	83000-05601	WINDOW HEAT
8DJ81LXG2	TACH. IND.	83000-05602	WINDOW HEAT
8DJ81LXG2	TACH. IND.	83000-05603	WINDOW HEAT
83000-05604	WINDOW HEAT		
8550-10	FIRE DETECTOR		
87001	SPEAKER		
87001-2	SPEAKER		
87001-3	SPEAKER		
88000-4102	CLOCK		
88000-4103	CLOCK		
88000-4104	CLOCK		
88000-4115	CLOCK		
8870-XX	FIRE DETECTOR		
8880-XX	FIRE DETECTOR		
894481	FIRE DETECTOR		
896386	SENSING ELEMENT		



Repair Station #S7HR883J EASA# .145.5336 Air Agency Certificate Number S7HR883J JAA Approval Number 5336

896387	SENSING ELEMENT
896388	SENSING ELEMENT
896767	FIRE DETECTOR
896768	FIRE DETECTOR
896798	FIRE DETECTOR
899315-XX	FIRE CONTROL MOD.
899319	FIRE DETECTOR
899321	FIRE DETECTOR
899323	FIRE DETECTOR
901950-XX	FIRE CONT. MOD.
902013	FIRE DETECTOR
902014	FIRE DETECTOR
902016-01	FIRE DETECTOR
902018-01	FIRE DETECTOR
902020	FIRE DETECTOR
902862	FIRE DETECTOR
902864	FIRE DETECTOR
948894-4-1	TEMP. CONTROL SW.
948894-5	TEMP. CONTROL. SW.