



Repair Station #S7HR883J EASA# .145.5336 Air Agency Certificate Number S7HR883J JAA Approval Number 5336

Embraer 145 Overhaul Capabilities

Part #	Description	Part #	Description
46110228900	FAN ASSY.	SYLC 51836 / -1	ACTUATOR
526484	ELECTRIC FAN	BYLB51971 /-1	ELECTRIC VALVE
524864	INVERTER	011768500	BAGGAGE VENT FAN
4800-101	PUSH BUTTON SWITCH	815289-1 / -2	TEMP. SENSOR
C142398-4-005 / -006	TEMP. CONTROL	8271500-XXX	CD PLAYER
SCD130-2-1	SPEAKER	SCD130-3-2	SPEAKER
H10-40	HEAD PHONE / MIC	H10-60	HEAD PHONE / MIC
30086-010	GENERATOR	30086-011	GENERATOR
51545-001B	GEN. CONTROL	51545-002A	GEN. CONTROL
51525-014A	GEN. CONTROL	23080-013A	STARTER GENERATOR
P2-07-0009-120	FLASHLIGHT	P2-07-0011-100	FLASHLIGHT
3601-133	FIRE DETECTOR	3601-134	FIRE DETECTOR
3601-135	FIRE DETECTOR	902081	FIRECONTROL MODULE
FDS765A-2	SMOKE DETECTOR	FAU751A-4	SMOKE DETECTOR
PU90-431R1	SMOKE DETECTOR	473597-13	SMOKE DETECTOR
145-34145-401	W/S WIPER MODULE	3801D2	W/S HEAT CONTROL
0871HT3	ICE DETECTOR	145-35259-401 / -405	GLARESHIELD LIGHT
145-21343-401 /-403	LIGHT MODULE	145-35260-401 /-403	LIGHT MODULE
GMT4190-011	CLOCK	4800-105 / -106	PUSH BUTTON SW.
80-0694-2-4 / -5	AURAL WARNING UNIT	85-0446-7	COCKPIT LIGHT
1826-1	DIMMER CONTROL	55-0531-4-21	INVERTER
55-0531-6-21	INVERTER	7287103-507	CABIN LIGHT MODULE
BR9000-2 /-22	BALLAST	7317042-501	SIGN ASSY.
BF1-0010-006	LAV SIGN	2LA007278-30	READING LIGHT
7287102-501	ATT. CALL PANEL	7287505-501	STAIR LIGHT
10-1086-1	LIGHT ASSY.	6020-24	EXIT SIGN
4033-5	LAV DOME LIGHT	CDEL1009-1	LAV. LIGHT
7317041-505 / -509	LIGHT ASSY	B-6245-305	LIGHT ASSY.
2LA002607-12 /-14	LIGHT ASSY.	50-0291-1	LIGHT ASSY
30-2437-1 / -2	NAV LIGHT	60-5096-1	STROBE POWER UNIT
30-2667-1	STROBE LIGHT ASSY.	31-8835-1	STROBE LIGHT ASSY.
31-9129-1	STROBE LIGHT ASSY.	30-1033-61	LIGHT ASSY
30-2675-1	LIGHT ASSY	RPS1-B	EMER. BATTERY PACK
BC1-002-002	EMER. CABIN LIGHT	11059-1	TOILET TIMER

Please call if your number is not listed above.